



Shipping Traffic Using a Booking Number

Certain customers (primarily International customers) input their movement instructions into CN's Service Reliability System and receive a booking number. This booking number is used at the *Speed Gate* to relate a shipment to a movement request. This booking number is also used to invoice the customer for the freight movement.

- After confirming the driver's identification the gatestand will ask the driver whether the shipment has a booking number. The driver will input the booking number, which will identify the shipper and destination.
- After inputting the booking number the driver will be asked whether the shipment requires temperature protection and will be prompted for the unit's weight, seal number, and shipper's reference number.
- At the conclusion of the input the *Speed Gate* will print a transaction ticket for the driver.